


Engine & Cooling	Fuel	Ignition	Electrical	Running gear	Torque settings	Capacities	Notes & Illustrations
------------------	------	----------	------------	--------------	-----------------	------------	-----------------------



Automotive Technical DATA BOOK

Click on one of the buttons above to view data for this car. To return to this screen and make another choice, click anywhere on the data screen.

MENU

HELP

Engine and cooling system 440/460 1.6i 1991 to 1997

Type		B16F-109 SOHC 8V ¹
Capacity (cm ³) / number of cylinders		1596 / 4
Compression ratio / pressure	bar	10.0 / ≥11.0
Oil pressure	bar	2.0 [3.5]
Oil temperature	°C	80
Valve clearance - inlet	mm	0.20±0.05
- exhaust	mm	0.40±0.05
Firing order		1-3-4-2
No 1 cylinder position		FE
Thermostat opening temperature	°C	92
Radiator cap pressure	bar	1.5

Fuel system 440/460 1.6i 1991 to 1997

Idle speed - manual [auto]	rpm	900±50 N/A
Fast idle speed - manual [auto]	rpm	—
CO @ idle speed [3000 rpm] - see page VI	%	0.2 to 1.0 N/A
HC @ idle speed [3000 rpm] - see page VI	ppm	≤200
CO ₂ @ idle speed [3000 rpm] - see page VI	%	≥14.5
O ₂ @ idle speed [3000 rpm] - see page VI	%	—
Carburettor / fuel injection		Bendix
Type / ref		Fenix 3B MPI
Main jet / needle		—
Injection pressure	bar	3.3 to 3.4
Pump pressure	bar	3.5
Octane rating	RON	95[U]

Ignition system 440/460 1.6i 1991 to 1997

Type		AEI
Ignition coil		S100
Primary resistance	ohms	0.4 to 0.8
Ballast resistor	ohms	—
Voltage - Tmnl 15(+) to earth	V	—
Distributor		Fenix
Points gap (air gap)	mm	—
Dwell angle	° (%)	Electronic control
Condenser capacity	µF	—
Rotation		Clockwise
Ignition timing - basic [static	° Crankshaft @ rpm	Computer control N/A
V = Vacuum NV = No Vacuum		—
Total ignition advance	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Centrifugal check.	° Crankshaft @ rpm	Computer control
	° Crankshaft @ rpm	—
	° Crankshaft @ rpm	—
Vacuum range check	mbar	Computer control
Maximum vacuum advance	° Crankshaft	—
Spark plugs		Bosch/Champion
Type		WR6DC / RN7YC
Electrode gap	mm	0.70 to 0.80

Electrical system 440/460 1.6i 1991 to 1997

Battery	V / CC / RC	12 / 55Ah
Alternator voltage / full load current / engine rpm		13.5 to 14.5 / 63, 72 / 2500
Starter motor current / voltage - cranking	A / V	200 to 275 / 9.0
- locked	A / V	390 to 480 / 6.0

Running gear 440/460 1.6i 1991 to 1997

Brakes -		
Front (min. friction material thickness)	mm	2.0
Rear (min. friction material thickness)	mm	1.0

Tyres		
Saloon	Size	175/65x14: 185/60x14:185/65x15
Estate / Van	Size	—
Pressure - front / rear - Saloon	bar	2.1 / 1.9
- Estate / Van	bar	—

Front suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	0 to +2.0
Camber		-24'±30' N/A
Castor		+4°6'±30' N/A
King pin inclination		+13°15'±30' N/A

Rear suspension / wheel alignment

Toe-in (+) / Toe-out (-)	mm [°]	+3.0 to 5.0
Camber		-1°

Torque wrench settings 440/460 1.6i 1991 to 1997


Cylinder head - stage 1	Nm	30
- stage 2	Nm	70
- stage 3	Nm	Slacken, then 20
- stage 4	Nm	+ 123±2°
Big-end bearings	Nm	45
Main bearings	Nm	65
Clutch cover	Nm	22
Flywheel [driveplate]	Nm	53 N
Front hubs	Nm	230
Rear hubs	Nm	180
Wheel nuts / bolts	Nm	110
Spark plugs	Nm	25

Capacities 440/460 1.6i 1991 to 1997

Engine oil & filter	litres	5.3. 93 ▶94: 5.0. 94 ▶: 4.6
Gearbox - 4-speed [5-speed]	litres	3.4
Automatic transmission - refill	litres	—
Final drive	litres	WT
Cooling system	litres	7.0
Fuel tank	litres	60

Notes and Illustrations

¹90 ▶91: 69kW. 92 ▶93: 62kW. 93 ▶: 61kW



1596 cm³