

Installation instructions

Front Windshield

Instructions for Volvo 200



Changing of the front windshield.



Remove the trim around the front windshield.



Dismantle the windshield wipers.



Disassemble the decorative frame of the windshield using a lever tool.



Remove the old clips, where the decorative frame was attached.



To remove the windshield use tools such as a cutting wire.



Lead the wire between the windshield and the body. Cut the window completely free.



Remove the window and put it safely on the side.



Using a chisel remove the old glue.



Mix the Butyl Primer and shake properly.



Apply the Butyl Primer to the bodywork.



The next step involves applying Butyl Primer on the front windshield.

Installation instructions

Front Windshield

Instructions for Volvo 200



Apply the Butyl Primer around the bodywork.



Leave the protective paper on the back of the adhesive tape until the very end.



Rip the adhesive backing at the corners. This makes working around the corners easier.



Do not cut off the excess Butyl adhesive exactly, but leave about a 1cm overlap.



Press the Butyl adhesive securely in place.



Now pull off the protective backing of the adhesive.



Put the spacers under the adhesive tape.



Accurately place the windshield in place and press solidly.



Distribute the clips for the decorative frame uniformly on the windshield.



Remove the old seal from the decorative frame.



Put the new seal on the decorative frame.
Tip: Use a little silicone spray to help push on.



Place the assembled frame on the clips and press tightly. Align the seal properly. Finished!