

Volvo 1992 Version Identification Number (VIN) Decoding

VIN number breakdown	YV1 A X 45 4 X N 1 000000
Manufacturer's code =====	
=	+
Assigned by ISO	
Series / Trim Class =====	= = +
=	
A = 240, F = B and D (740 Series)	
J = E and G (940 series), K = C4 (960 Series)	
Safety system =====	= = = +
=	
S = 4-door w. airbag and seat belt tensioner	
W = 5-door w. airbag and seat belt tensioner	
T = 4-door w. manual seat belts (Canada)	
X = 5-door w. manual seat belts (Canada)	
Engine =====	= = = = +
=	
82 = B230F (LH3.1), 87 = B230F-Turbo	
88 = B230F (LH2.4), 89 = B234F, 95 = B6304F	
Emission =====	= = = = = +
=	
0 = 49 State w/o EGR Bosch; MFK 30/39	
1 = 50 State w/ EGR Bosch; MFK 31	
3 = 49 State w/o EGR Bendix; MFK 30/39	
Check figure =====	= = = = = +
=	
Calculated from other digits	
Year model code =====	= = = = = = +
=	
K = 1989, L = 1990, M = 1991, N = 1992	
Manufacturing plant =====	= = = = = = = +
=	
0 = Kalmar, Sweden, 1 = Gothenburg, Sweden	
2 = Ghent, Belgium, 3 = Halifax, Canada, A = Uddevalla Sweden	
Chassis number =====	= = = = = = = = +
=	
For 1992 year models, the serial numbers start at:	
240 4 door ... 457500 , 240 5 door ... 910500	
740 4 door ... 531000 740 5 door ... 342700	
940 4 door ... 52900, 940 5 door ... 28000	
960 4 door ... 14900, 960 5 door ... 4700	